



INTERFACE DISCRIPTION



PARAMETER SETTING PROCESS



2.3 PARAMETER LIST

ITEM	Default	Min	Max	Unit	Description
01	10	0	30	mm/s	In the auto mode, maximum tracking speed
02	10	0	30	mm/s	In the manual mode, maximum manual speed
03	REV/FWD				The logical relationship between motor direction and the material deviation
04	DIS/USE				Parking brake function
05	Serv/OUT				Through an external sensor or Operation to reset the actuator
06	50%	0%	100%		The intermediate position occupy the total stroke percentage
07	5%	0%	100%		The dead zone occupy the total detecting range percentage
08	80%	0%	100%		The acceleration zone occupy the total detecting range percentage
09	0%	0%	100%		The first acceleration zone occupy the total detecting range percentage
10	10%	0%	100%		The max speed in first acceleration zone occupy the max tracking speed percentage
11	50%	0%	100%		The sensor reference point in the position of the total detecting range
12	0%	0%	100%		Material damage identification range, beyond this range, start the following speed
13	0%	0%	100%		Detecting material damage, running speed occupy the max tracking speed percentage
14	100	0	255	\$	Detecting material damage start timer, beyond this range, the actuator reset
15	SLAV/MAIN				In the network condition, the host controller can control the subsidiary controller.
16	1	1	30		The address of this controller.
17	(指令)				The instruction of establishing communication.
18	01	01	30		The instruction of establishing communication.
19	MAN/CENT/AUTO				The state of system when power on
20	DIS/ONON/GAP				The output state of limited alarm
21	**				The function of start/stop port setting.
22	**				
23	**				
24	**				
25	**				